

USER MANUAL



G03

www.fslscoreboards.com

info@fslscoreboards.com

+44 (0)28 8676 6131



Sports Technology Solutions

Discover more at www.fslscoreboards.com

know the score...


1) Scoreboard connections:

- The scoreboard should be supplied with a 230V mains supply.
- The mains supply should be fed through a 5 amp circuit breaker and it is highly recommended that the supply should be fed through a Residual Current Device (RCD)
- If the scoreboard has been supplied with a separate aerial this should be mounted as high as possible


2) On Power Up:

- 'Sync' will be displayed briefly (*this is the display syncing with the real time clock*)
- 'Cd - ' will be displayed for 5 seconds
 - This is a "code" number stored in memory
- The scoreboard will now go into normal operation, displaying scores with the clock blanked.


3) Changing Scores:



1) Pressing the appropriate button on the transmitter will increase the corresponding score display by one.



2) To “Decrease” the score press the “DEC” button and the appropriate score button **together**. The score will decrement by one each time.



3) To clear the score back to zero press both the “GOAL” & “POINT” together.


4) Team name Setting:

The team names will be stored into memory and will be displayed each time the scoreboard is switched on.



To enter team name setup
press  &  switches together

To change the letter to be adjusted press the appropriate button on the transmitter to move the flashing underscore to the right or left
e.g. “T_!” to “TE_” There are separate buttons for the home & away teams



The letter to be changed in the team name will start to flash between the current stored letter and an underscore

e.g. “S” then “_” then “S”




To increase the letter press the button

e.g. “A” then “B” then “C”



To decrease the letter press the button

e.g. “C” then “B” then “A”



To store the team names into memory and resume normal operation press & switches together

The display will show all colons as above and then return to normal scoring display

5) Brightness Setting:

- To access brightness setting, hold buttons  &  on the handset together for 3 seconds until 'bl - ' is displayed
- To exit brightness setting, hold buttons  &  on the handset together for 3 seconds until the scores are displayed again



Increasing Brightness:

- While 'bl - ' is displayed, increase brightness with button 
- The maximum brightness is 9




Decreasing Brightness:

- While 'bl - ' is displayed, decrease brightness with button 
- The minimum brightness is 0



- To exit brightness setting, hold buttons  &  on the handset together for 3 seconds until the scores are displayed again

6) Scoreboard Blank:



To blank the scoreboard display, press the  & . The score will be restored if any score button is pressed.

7) Time Mode Menu:

- To access '**Time Mode Menu**', hold button  for 3 seconds until '**TOD**' is displayed



- Pressing button  will scroll through the 4 time menu options, displayed as :
 - '**tod**' – Time of day in hours and minutes (Real time clock)
 - '**tu**' – Timer up in minutes and seconds
 - '**td**' – Timer down in minutes and seconds
 - '**bln**' – Blank/clear the clock
- While displaying one of the time options above, holding button  for 3 seconds will go into that corresponding option

NOTE: Defaults to blank clock on power up

7.1) While in 'tod' (Time of Day in hours & minutes):

- The clock setting that can be changed will flash
- Press button  to switch through hours and minutes setting

- Press button  to **INCREASE** the hours/minutes

- Press button  **RESET** NAMES to **DECREASE** the hours/minutes



- To store and display the '**Real Time Clock**', hold button  for 3 seconds until 'STORE' is displayed.

While displaying the '**Real Time Clock**', hold button  for 3 seconds to go into the '**Time Mode Menu**' again

NOTE: 'Time Mode Menu' cannot be accessed when brightness is being set

7.2) While in 'tu' (Timer Up in minutes & seconds):

- **NOTE:** 'SET START' will be displayed. Set Timer Up's starting time.

- Press button  to switch through minutes and seconds setting

- Press button  to **INCREASE** the minutes/seconds

- Press button  **RESET** NAMES to **DECREASE** the minutes/seconds



- To store *Timer Up's* starting time, hold button  for 3 seconds
- **NOTE:** 'SET STOP' will be displayed. Set *Timer Up's* stopping time.

- To store *Timer Up's* stopping time and display the '**Timer Up**',
hold button  for 3 seconds until 'STORE' is displayed.

- Press button  to **START/STOP** the timer



- **ONLY** if timer is STOPPED press button  to **RESET**
the timer to start time



While displaying the 'Timer Up', hold button  for 3 seconds to go into the 'Time Mode Menu' again

7.3) While in 'td' (Timer Down in minutes & seconds):

- The timer setting that can be changed will flash
- Press button  to switch through minutes and seconds setting

- Press button  to **INCREASE** the minutes/seconds

- Press button  **RESET** NAMES to **DECREASE** the minutes/seconds



- To store and display the 'Timer Down', hold button  for 3 seconds

- Press button  to **START/STOP** the timer



- **ONLY** if timer is STOPPED press button to **PRESET** the timer to what it was previously set

While displaying the '**Timer Down**', hold button  for 3 seconds to go into the '**Time Mode Menu**' again

7.4) While in 'bln' (Blank Clock):

NOTE: Defaults to clearing the clock

While displaying the '**Blank Clock**', hold button  for 3 seconds to go into the '**Time Mode Menu**' again



FSL ELECTRONICS LTD
SANDHOLES ROAD
COOKSTOWN
CO TYRONE
N. IRELAND
BT80 9AR